

Dimension

295 \* 127 11.6 \* 5

L 295

## RCP-1000 series

Н	
41 (1U)	mm
1.61(1U)	inch







### Features

- · Universal AC input / Full range
- · Built-in active PFC function
- High efficiency up to 89%
- Forced air cooling by built-in DC fan
- Output voltage programmable
- · Built-in OR-ing diode, support hot swap (hot plug)
- · Active current sharing up to 3000W for one 19" rack shelf
- Built-in I<sup>2</sup>C interface (RCP-1000-C models only)
- Protections: Short circuit / Overload / Over voltage / Over temperature
- Optional conformal coating
- 5 years warranty



## Applications

- Industrial automation
- Distributed power architecture system
- Wireless/telecommunication solution
- Redundant power system
- Electric vehicle charger system
- Constant current source system

### GTIN CODE

MW Search: <a href="https://www.meanwell.com/serviceGTIN.aspx">https://www.meanwell.com/serviceGTIN.aspx</a>

### Description

RCP-1000 is a 1KW single output rack mountable front end AC/DC power supply This series operates for 90~264VAC input voltage and offers the models with the DC output mostly demanded from the industry. Each model is cooled by the built-in DC fan with fan speed control, working for the temperature up to 60°C. RCP-1000 provides vast design flexibility by equipping various built-in functions such as the output programming, active current sharing (up to 8000W via three 19" rack shelves, RCP-1U), remote control, auxiliary power, alarm signal, etc.

## Model Encoding / Order Information



X Note: 19" rack shelf, RCP-1U, available. Details available on http://www.meanwell.com/



### SPECIFICATION

MODEL		RCP-1000-12	RCP-1000-24	RCP-1000-48		
	DC VOLTAGE	12V	24V	48V		
	RATED CURRENT	60A	40A	21A		
	CURRENT RANGE	0~60A	0~40A	0~21A		
	RATED POWER	720W	960W	1008W		
	RIPPLE & NOISE (max.) Note.2		200mVp-p	300mVp-p		
Ουτρυτ	VOLTAGE ADJ. RANGE(SVR)		23.2 ~ 24.8V	46.3 ~ 49.7V		
0011101	VOLTAGE TOLERANCE Note.3		±1.0%	±1.0%		
		±0.5%	±0.5%	±0.5%		
	LOAD REGULATION	±0.5% ±0.5%				
	SETUP, RISE TIME	1000ms, 60ms/230VAC at full load				
	HOLD UP TIME (Typ.)	16ms/230VAC at full load				
	VOLTAGE RANGE Note.4	90 ~ 264VAC 127 ~ 370VDC				
	FREQUENCY RANGE	47 ~ 63Hz				
NDUT	EFFICIENCY (Typ.)	81%	87%	89%		
INPUT	AC CURRENT (Typ.)	8.5A/115VAC 4.5A/230VAC	10.5A/115VAC 5.5A/230VAC	11A/115VAC 5.5A/230VAC		
	INRUSH CURRENT (Typ.)	COLD START 50A				
	LEAKAGE CURRENT	<1.1mA/230VAC				
		105 ~ 125% rated output power				
	OVERLOAD		recovers automatically after fault condition i	s removed		
DEATECTION		13.2 ~ 16.2V	26.4 ~ 32.4V	52.8 ~ 64.8V		
PROTECTION	OVER VOLTAGE	Protection type : Shut down o/p voltage, re		52.0 04.00		
	OVER TEMPERATURE	Shut down o/p voltage, recovers automatic	any after temperature goes down			
	AUXILIARY POWER	5V @ 0.3A				
	REMOTE ON-OFF CONTROL	By electrical signal or dry contact ON:sh	1			
	REMOTE SENSE	Compensate voltage drop on the load wirin				
FUNCTION	OUTPUT VOLTAGE PROGRAMMABLE	Adjustment of output voltage is allowable	e to 90 ~ 110% of nominal output voltage. P	lease refer to the Function Manual.		
	DC OK SIGNAL	The isolated TTL signal out, Please refer to the Installation Manual				
	AC OK SIGNAL	The isolated TTL signal out, Please refer to	o the Installation Manual			
	OVER TEMP WARNING	Logic " High" for over temperature warning	, Please refer to the Installation Manual, isol	ated signal		
	WORKING TEMP.	-20 ~ +60°C (Refer to "Derating Curve")				
	WORKING HUMIDITY	20 ~ 90% RH non-condensing				
ENVIRONMENT	STORAGE TEMP., HUMIDITY	-40 ~ +85°C, 10 ~ 95% RH non-condensing				
	TEMP. COEFFICIENT	±0.02%/°C (0~50°C)				
	VIBRATION	10 ~ 500Hz, 2G 10min./1cycle, 60min. ead	ch along X Y Z axes			
	SAFETY STANDARDS		BS EN/EN62368-1, EAC TP TC 004 approve	ad		
	WITHSTAND VOLTAGE	I/P-O/P:3KVAC I/P-FG:2KVAC O/P-F		54		
	ISOLATION RESISTANCE	I/P-O/P, I/P-FG, O/P-FG:100M Ohms / 500				
	ISOLATION RESISTANCE	Parameter		Test Level / Note		
		Conducted	BS EN/EN55032 (CISPR32)	Class B		
	EMC EMISSION	Radiated	BS EN/EN55032 (CISPR32)	Class B		
		Harmonic Current	BS EN/EN61000-3-2			
		Voltage Flicker	BS EN/EN61000-3-3			
SAFETY &		BS EN/EN55024, BS EN/EN61000-6-2				
ЕМС	EMC IMMUNITY	Parameter	Standard	Test Level / Note		
(Note 5)		ESD	BS EN/EN61000-4-2	Level 3, 8KV air ; Level 2, 4KV contact		
		Radiated	BS EN/EN61000-4-3	Level 3		
		EFT / Burst	BS EN/EN61000-4-4	Level 3		
		Surge	BS EN/EN61000-4-5	Level 4, 4KV/Line-Earth ; Level 3, 2KV/Line-Li		
		Conducted	BS EN/EN61000-4-6	Level 3		
		Magnetic Field	BS EN/EN61000-4-8	Level 4		
		Voltage Dips and Interruptions	BS EN/EN61000-4-11	>95% dip 0.5 periods, 30% dip 25 period >95% interruptions 250 periods		
	MTBF	840.8K hrs min. Telcordia SR-332 (Bell	⊥ core) ; 107.4K hrs min. MIL-HDBK-217F (			
OTHERS	DIMENSION	295*127*41mm (L*W*H)	,,	· /		
CTTLING	PACKING	1.93Kg; 6pcs/12.6Kg/1.04CUFT				
NOTE	<ol> <li>All parameters NOT special</li> <li>Ripple &amp; noise are measure</li> <li>Tolerance : includes set up</li> <li>Derating may be needed ur</li> </ol>	ly mentioned are measured at 230VAC inp d at 20MHz of bandwidth by using a 12" t tolerance, line regulation and load regulation ider low input voltages. Please check the c ered a component which will be installed in	derating curve for more details. nto a final equipment. All the EMC tests are	7uf parallel capacitor.		







#### Function Manual

#### 1. Voltage Drop Compensation

#### 1.1 Remote Sense

The remote sense compensates voltage drop on the load wiring up to 0.5V.



#### 1.2 Local Sense

% The +S,-S have to be connected to the +V,-V, respectively, as the following diagram, in order to get the correct output voltage if Remote Sense is not used.



#### 2. Remote ON/OFF Control

The power supply can be turned ON/OFF together or separately by using the "Remote ON-OFF" function.







3. Output Voltage Programming (or, PV / remote voltage programming / remote adjust / margin programming / dynamic voltage trim) ※ In addition to the adjustment via the built-in potentiometer, the output voltage can be trimmed to 90~110% of the nominal voltage by applying EXTERNAL RESISTANCE.



#### 4. I<sup>2</sup>C Bus Interface

% For the details of I^2C bus used on RCP-1000-C models, please refer to the Installation Manual.





#### % LED Status Indicators & Corresponding Signal at Function Pins

Function	LED	Description	* Signal	PSU Output
AC-OK	ON	When input voltage≧82V±4V	0~0.5V	ON
AC-NG	OFF	When input voltage≦82V±4V	4.5~5.5V	OFF
DC-OK	ON	When output voltage $\geq$ 80% $\pm$ 5% of Vo rated.	0~0.5V	ON
DC-NG	OFF	When output voltage $\leq$ 80% $\pm$ 5% of Vo rated.	4.5~5.5V	ON
T-OK		When the internal temperature (TSW1 & TSW2 short) is within safe limit	0~0.5V	ON
T-ALARM		When the internal temperature (TSW1 or TSW2 open) exceeds the limit of temperature alarm	4.5 ~ 5.5V	OFF

\*Signal between function pin and "-V".

#### % Input / Output Connector Pin No. Assignment(CN501) : Postronic PCIB24W9M400A1

1	3 5	7 10 13 16 19	23
	00	00000 00000 00000	0 0
2	-	9 12 15 18 21	22 24

Mating Housing Postronic PCIB24W9F400A1

Pin No.	Function	Description	
1,2,4	+V(signal)	Positive output voltage.	
3,5,6	-V(signal)	Negative output voltage.	
7	RemoteON-OFF	Each unit can separately turn the output on and off by electrical or dry contact . Short: ON, Open:OFF.	
8	+S	Positive sensing for Remote Sense.	
9	-S	Negative sensing for Remote Sense.	
10	AC-OK	_ow : When input voltage is ≧82Vrms +/-4V. High : When input voltage in≦82Vrms +/-4V.	
11	DC-OK	High : When Vout≤ $80\%$ +/-5%. Low : When Vout ≥ $80\%$ +/-5% (Note.1)	
12	CS	Current sharing signal. When units are connected in parallel, the CS pins of the units should be connected to allow current balance between units.	
13	V-TRIM	Connection for output voltage programming.	
14	T-ALARM	High : When the internal temperature is within safe limit. Low : 10°C below the thermal shut down limit.	
15	+5V-AUX	Auxiliary voltage output, 4.3~5.3V, referenced to GND-AUX(pin 7). The maximum load current is 0.3A. This output has the built-in "Oring diodes" and is not controlled by the remote ON/OFF control.	
16	GND-AUX	Auxiliary voltage output GND. The signal return is isolated from the output terminals (+V & -V).	
17	SCL	Serial clock used on RCP-1000-C models. Refer to the Instruction Manual. (Note.1)	
18	SDA	Serial data used on the RCP-1000-C models. Refer to the Instruction Manual. (Note.1)	
19,20,21	A0,A1,A2	I <sup>2</sup> C interface address lines used on RCP-1000-C models. Refer to the Instruction Manual.	
22	FG	AC Ground connection.	
23	AC/L	AC Line connection.	
24	AC/N	AC Neutral connection.	

Note1: Non-isolated signal, referenced to the output terminal -V.